

Parameter	Type	P-FL-24/20.D	P-FL-48/20.D	P-FL-220/20.D	P-FL-1200/40.PV

Dimension

Removing steps are as follows

Installation


The apparatus can be mounted on a DIN 35 mm standard rail corresponding to DIN EN 60715, they must be snapped onto the rail, and never slanted or tipped to the side.

Installation steps are as follows

- a) When removing the SPD, as shown in arrows 1 and 2, screw the spring pin outward with the screwdriver, rotate the SPD and take off the SPD.
- b) When removing the module, as shown in arrows 3 and 4, pinch the side edge of the module as shown in the figure and pull out the module.

Connections

Maximum torque of the screw is 3 N.m



Installation

- a) When installing the SPD, as shown in arrows 1 and 2, make the bayonet locked into the guide rail, Press the spring pin slightly and make the SPD on the DIN guide rail.
- b) When installing the module, make the arrow on the module and the pedestal at the same side, aim at card slot, then pinch the module as shown in arrows 3 and push in. The sound of "Ka" slight means completion.